



OPUS multiROLO A3

PL Instrukcja obsługi

1 ZASADY BEZPIECZEŃSTWA

Obcinarka krążkowa OPUS multiROLO A3 jest wygodnym urządzeniem do cięcia papieru i kalki (nie zalecana do cięcia folii, kartonów i papierów powlekanych). Ostrze i listwa docinająca są wykonane z odpowiedniej, wysokogatunkowej stali, zaś kształt elementów tnących powoduje ich samoosłrenie. Obcinarka wyposażona jest w praktyczne rysunki popularnych formatów oraz podziałkę milimetrową.

- Przed rozpoczęciem pracy z urządzeniem, należy zapoznać się z zasadami bezpieczeństwa, zaleceniami producenta i instrukcją obsługi. Instrukcję należy zachować i korzystać z niej w przypadku jakichkolwiek wątpliwości dotyczących obsługi urządzenia.
- Urządzenie służy wyłącznie do cięcia papieru. Papier specjalny (np. kredowany) lub karton należy ciąć pojedynczo.
- Nie należy ciąć jednorazowo większej ilości papieru niż ilość maksymalna (patrz: Dane techniczne).
- **Urządzenie należy trzymać z dala od dzieci i zwierząt.**
- Urządzenie posiada ostre elementy tnące należy zachować szczególną ostrożność przy wykonywaniu cięcia, istnieje ryzyko skałeczenia.
- Przy wykonywaniu cięcia należy zwrócić szczególną uwagę na luźne elementy garderoby.
- Urządzenie należy ustawić na płaskiej, stabilnej powierzchni.

2 OBSŁUGA

- Przesuń wstępnie nóż do oporu w lewą stronę.
- Położyć arkusz papieru lub innego materiału przeznaczonego do cięcia na stół.
- Wsuń papier pod listwę docisku i dosuń do lewego lub prawego brzegu.
- Przy przecinaniu przyciśnij dodatkowo kartki do stołu.
- Przesuń nóż po prowadnicy wywierając dodatkowo niewielki nacisk w kierunku ostrza przytwierzonego do stołu dla uzyskania lepszego efektu cięcia.
- Przecinanie może następować również w przeciwnym kierunku.

3 WYMiana NOŻA

Urządzenie posiada możliwość wymiany noża w zależności od rodzaju cięcia (proste, faliste, perforowane). Aby wymienić nóż podnieś do góry oslonę noża (osłona z jednej strony zamontowywana jest na zawiasie). Wyjmij zainstalowany nóż, wysuwając go do góry, a następnie włożyć nowy, wsuwając go w dół. Zamknij oslonę noża.

4 DANE TECHNICZNE

Obcinarka OPUS multiROLO A3 przecina maks.:.....	7 kartek (papier 70 g/m ²)
Długość cięcia:.....	460 mm
Wymiary stołu roboczego (S x G):	460 x 280 mm
Wymiary (W x S x G):.....	70 X 560 X 330 mm
Waga netto:.....	0,9 kg
Waga brutto:.....	1,1 kg



OPUS multiROLO A3

EN User guide

1 BASIC SAFETY PRECAUTIONS

OPUS multiROLO A3 is a easy to use trimmer for cutting paper, (it is not recommended to cut foil, card and coated paper). A blade and blade bar are made of high quality steel. Their shape has been specially design so that they self-sharpen when used.

On the cutting table is marked with the most popular formats of paper it also has measuring scale.

- Before using the equipment please read the Health & Safety precautions, manufacturers' recommendations and the operating manual.
- The operating manual should be available at all times for the operator to read.
- The equipment is intended for cutting paper only. None standard paper, e.g. coated paper, chalked paper or card should be cut one at a time when trimming.
- The equipment should be kept out of reach of children and animals.
- Do not exceed the maximum number of sheets when trimming.
- **Danger!! The equipment contains sharp elements – pay special attention during trimming.**
- Keep loose-fitting clothes away from the trimmer during operating.
- The equipment must be used on a strong and sturdy surface.

2 OPERATION

- To cut paper move the blade to the left or right as far as possible.
- Put a piece of paper or other material on the cutting table.
- Slide the paper under the clamp bar and push it to the right or left edge of the trimmer.
- When trimming press firmly the clamp bar with your hand.
- Holding the paper with your hand, slide the blade along the bar, pushing firmly on blade handle.
- Trimming can be made in both directions.

3 FITTING A DIFFERENT BLADE

The unit gives you the option to use 3 types of blades, straight, wavy and perpetrated. Lift handle on the blade holder, slide upwards the old blade and replace with the new blade then close the handle.

4 TECHNICAL DATA

Maximum straight cut capacity:7 sheets / A4 70 g/m ²
Cutting length:460 mm
Dimensions of base:W 460 x D 280 mm
Dimensions:H 70 x W 560 x D 330 mm
Net weight:0.9 kg
Gross weight:1.1 kg